

S Sandberg®
ACTIVE 

Survivor Powerbank 10000


Quick guide

420-60



www.sandberg.world


Product overview




- 1. Compass
- 2. Switch on/off
- 3. Silicone cover

- 4. Hanging ring
- 5. Indicator lights
- 6. Anti-skid grip


Open silicone cover




Charge Powerbank




Charge devices



Pocket light



1. Press for 3 seconds to
turn on



2. Press for 3 seconds to
turn off



Support

<http://helpdesk.sandberg.world>

Warranty

*There is a five-year warranty on your Sandberg product.
Please read the warranty terms and register your new
Sandberg product at www.sandberg.world/warranty*

5
Years
Warranty

For information on handling electronic waste, see www.sandberg.world/weee

